

Index

A

Advanced Product Quality Planning
(APQP), 116

Akao, Yoji, 26

alias, 177

Altshuller, Genrich Saulovich, 78–79,
111

contradiction matrix, 81–82

40 inventive principles, 103–111

Table of Contradictions, 86

American Society for Quality (ASQ), 116

analysis of variance (ANOVA), 67, 69, 78

another dimension principle, 106–107

antiweight principle, 104–105

arrays

inner, 15–20, 38

orthogonal, 34–38

outer, 43–45

asymmetry principle, 104

automotive industry, 115

Automotive Industry Action Group
(AIAG), 116, 129–130

average quality loss function, 208–209

B

ball-swirling example, 17–19, 44, 70–71

basic quality attributes, 27–30

“bathtub curve pattern,” 238

beforehand cushioning principle, 105

β symbol, 170

beverage can example, 82, 86–92

black noise, 101

“blessing in disguise” principle, 107–108

B_q life, 223

brainstorming, 13, 174

brute-force design technique, 64

INDEX

C

- carpet clip example, 237
- categories of failure, 119
- cause, 122–123, 127–128
- cheap short-living objects principle, 108
- CNC. *See* Computer Numerical Control (CNC)
- Code of Federal Regulations (CFR), 115
- color changes principle, 109
- common-cause variation, 235–237
- compensating for noise, 152–153
- composite materials principle, 111
- compounding noises, 47
- compromise, 79
- Computer Numerical Control (CNC), 47
- Concept Design, 156–158
- confounding, 37, 177
- continuity of useful action principle, 107
- contradiction, 79–80, 85
 - law of, 86
 - matrix, 81
 - physical, 81
 - Table of, 86
 - technical, 81
- control array. *See* inner array
- control factor, 12–20, 173
 - effects, 93–96
 - Kano Model, 34–38
 - levels, 34–40
 - P-Diagram, 140, 141
- control types, 129
- copying principle, 108
- cost–benefit analyses, 208
- Cost of Poor Quality (COPQ), 139, 203
- Critical-to-Quality (CTQ)
 - characteristics, 6–7, 51
 - flow-down, 63
 - measuring, 71–73
- current controls, assessing, 129–131
- cushioning principle, 105
- customer
 - data collection, 5, 52–55
 - dissatisfaction, 148
 - intent, 168
 - loyalty, 224
 - metrics, 9
 - usage profiles, 142

D

- data collection, 5, 52–55
- decibel scale, 146, 191
- defects per million opportunities (DPMO), 245
- Deming, W. E., 26
- design, experimental, 139–147, 157, 200
- design factor matrix, 65
- Design FMEA failure detection
 - ranking system, 128, 130
- design for robustness, 226–228, 230, 251–252

- Design for Six Sigma, 225–230,
244–247
- design-in function, 227
- design, intelligent, 64
- design of experiment (DOE), 19–20,
35–38, 63–68
- matrix, 66
- design-out failure, 227–228
- design, probabilistic, 241
- design, process map for robust, 251–252
- design risk assessment, 131
- design variables, 241
- detection values, 129
- deterioration, 142
- discarding and recovering principle, 110
- distributions, stress–strength, 232–235
- documentation, of failures, 114
- DOE. *See* design of experiment
- donut example, 10–12
- dot plot, 70
- dynamic characteristic, 191
- dynamic Parameter Design, 158
- dynamic response, 2, 164–166, 179
- dynamics principle, 106
- E**
- effects, 122–123
- effects and consequences, and FMEA,
124–127
- electrostatic spray example, 197–199
- energy transformation, 8–12
- engineered system, 171
- engineering metrics, 9
- engineering parameters, 83–84
- equipotentiality principle, 105
- Excel function, NORMSDIST, 245
- excitement quality attributes, 27, 31–32
- experimental design
- matrix, 157
- and the P-Diagram, 139–147
- and Tolerance Design, 200
- experiments and testing, and QFD,
68–73
- F**
- factor effects, 97
- factor levels, 9–10, 38
- failure, 191, 223
- categories of, 119
- detection ranking system, 128, 130
- mode, 119, 122–124
- physics of, 219
- prevention of, 117–118
- rates, three-period pattern, 238
- failure, design-out, 227–228
- Failure Mode and Effect Analysis
(FMEA)
- cause, 120
- current controls, 129–131
- effect, 120
- effects and consequences, 124–127
- failure mode, 119–122
- failure prevention, 117–118
- functional diagram, 120

INDEX

Failure Mode and Effect Analysis

(FMEA) *continued*

functions, 118–119

manual, 116–117

origins and use, 114–117

potential, 122

risk management, 131–134

understanding causes, 127–128

Failure Mode, Effects and Criticality

Analysis (FMECA), 114

feedback control, 152

feedback principle, 108

feed-forward control, 153

Feigenbaum, Armand V., 26

fishbone relationship, 122–123

five reliability phases, 225–228

flexible shells and thin films principle,
109

flowchart, robust design strategy, 159

40 inventive principles, 84–92

list of, 103–111

parameter changes, 90–92

segmentation, 86–88

spheroidality, 88–90

F-test, 78

function, 118–120, 122–123

design-in, 227

design-out failure, 227–228

in goal tree, 56

ideal, 144–147, 166, 168–171

functional diagram, 120

G

goalpost mentality, 147, 205

goal tree, 55–58

gyrocopter example, 165–192

H

Herzberg's Motivator-Hygiene Theory,
25–26

homogeneity principle, 110

House of Quality, 60–62

hygiene factors, 26

I

ideal function, 144–147, 166, 168–171

ignoring noise, 152

inert atmosphere principle, 111

inner array, 15–20, 38

inputs, 140, 159, 164, 192, 215, 252

intelligent design, 64

interaction analysis, 38–40

interaction effects, 99–102

intercept, 144

intermediary principle, 108

International Code of Safety for High-
Speed Craft, 115

International Organization for
Standardization (ISO), 115

inventive principles, 84–92, 103–111

Ishikawa, Kaoru, 26

ISO 9000, 115

ISO/TS 16949, 116

J

job satisfaction, 26
Juran, Joseph, 26

K

Kano, Noriaki, 26, 49
 definitions of quality, 27–29
Kano Model, 27
 control factor levels, 34–38
 early development, 25–32
 and Herzberg's Motivator-Hygiene Theory, 25
 noise-by-control analysis, 38–40
 noise factors, 45–47
 outer array, 43–45
 quality types over time, 32–34
 variability reduction, 40–42

L

laptop computers example, 228–230
larger-the-better, 2, 34, 43, 206–207
law of contradiction, 86
“lemons into lemonade” principle,
 107–108
levels, 9–10
lightbulb example, 119–122
 and FMEA form, 133
local quality principle, 104
long-term data, 247
Long-Term Dynamic Mean Variation,
 247

L_8 orthogonal array, 16, 19, 175
 L_{12} orthogonal array, 35
 L_{18} orthogonal array, 36–37
Loss to Society, 26, 64, 147–148, 204
lower specification limit (LSL), 148

M

management metrics, 9
maritime industry, 115
market research, 52–55
matrix
 contradiction, 81
 design of experiment, 66
 design factor, 65
 noise factor, 65
 product planning, 58–63
 Pugh, 78
mean squared deviation (MSD), 188
mean squared error (MSE), 188
mean time between failure (MTBF), 223
mean time to failure (MTTF), 223
mechanical vibration principle, 107
mechanics substitution principle, 109
medical devices, 116–117
merging principle, 104
metrics, 6, 34, 169
 engineering, 9
 reliability, 221
 types of, 9
 and VOC, 168
Military Procedure MIL-P-1629, 114

INDEX

Mizuno, Shigeru, 26
motivator factors, and job satisfaction,
26
Motorola, and Long-Term Dynamic
Mean Variation, 247

N

negation, 80
“nested doll” principle, 104
noise, 65
 black and white, 101
 compensating for, 153–153
 compounding, 47
 factor effects, 96–99
 management strategies, 152–155
noise-by-control analysis, and Kano
 Model, 38–41
noise factor (NF), 12–20, 172, 173, 178
 allocation to outer array, 43–44
 categories, 14
 identifying, 151
 Kano Model, 45–47
 management, 150–155
 matrix, 65
 P-Diagram, 140, 142
 uncontrollable, 46, 142, 150–151
noise level
 averages, 96
 reproducible, 46
nominal-the-best, 2, 34, 206
NORMSDIST, Excel function, 245

O

operational definitions, 68–69
orthogonal arrays, 34–38
 of control factors, 15
“the other way around” principle,
105–106
outer array, Kano Model, 43–45
outliers, 93
outputs, 152, 159, 192, 215, 252
output variation, 213, 245

P

paint spray example, 197–199
parameter changes, 90–92
parameter changes principle, 110
Parameter Design, 156–158
 control factors, 174–178
 data analysis, 186–192
 data collection, 183–186
 dynamic, 171–174
 experiment, 183
 ideal function, 168–171
 introduction, 163–165
 noise factors, 178–182
 project and team selection,
 166–168
 stage, 64
 static, 157
Parameter Diagram (P-Diagram)
 control factors, 140
 experimental design, 139–147

- noise factor management, 150–155
 - noise factors, 140
 - quality loss function (QLF), 147–150
 - sample, 145
 - Taguchi's three phases, 156–158
 - partial or excessive actions principle, 106
 - perceived result, 5, 168
 - performance characteristic, 191
 - performance of CTQs, 147–148
 - performance quality attributes, 27, 30
 - periodic action principle, 107
 - phase transitions principle, 110
 - physical contradiction, 81
 - physics of failure, 219
 - pneumatics and hydraulics principle, 109
 - point estimate, 222
 - porous materials principle, 109
 - potential, and FMEA, 122
 - preliminary action principle, 105
 - preliminary anti-action principle, 105
 - prevention of failure, 117–118
 - probabilistic design, 241
 - process elements, 252
 - Process Failure Mode and Effect Analysis (Process FMEA), 128
 - process map, for robust design, 251–254
 - product planning matrix, 58–63
 - Pugh matrix, 78
- Q**
- QFD. *See* Quality Function Deployment
 - QS-9000, 115
- Quadratic Loss Function. *See* quality loss function
- quality, 220
 - basic attributes, 27–30
 - definitions of, 27–29
 - excitement attributes, 27, 31–32
 - improvement, 209
 - Kano's definitions of, 27
 - performance attributes, 27, 30
 - types over time, 32–34
 - versus-cost tradeoffs, 203–204
 - quality control, statistical, 26
 - Quality Function Deployment (QFD)
 - design of experiments, 63–68
 - experiments and testing, 68–73
 - goal tree, 55–58
 - House of Quality, 58–63
 - market research, 52–55
 - quality loss function (QLF)
 - average, 208–209
 - example, 208
 - P-Diagram, 147–150
 - Taguchi's, 149–150
 - Tolerance Design, 204–210
 - quality types over time, 32–34
- R**
- randomization, 183–184
 - ranking system
 - Design FMEA failure, 128
 - Design FMEA failure detection, 130
 - severity of effects, 126

INDEX

- reducing noise, 153
 - reduction in variability, 201–202
 - region of failure, 242–243
 - reliability, 220, 223–225
 - in critical components, 241
 - cycle, 225
 - as a metric, 221–223, 225–228
 - performance, 226
 - phases, 225–228
 - requirements, 225–228
 - reliability design
 - sigma calculations, 241–248
 - and Six Sigma, 220–230
 - stress–strength interference, 231–241
 - repairs per thousand, 223
 - resolution, and confounding, 177–178
 - response, 157, 169
 - response variables, 139
 - P-Diagram, 143–144
 - reusability, 228
 - risk assessment, 131
 - risk engineering and management, 114
 - risk management, 131–134
 - risk-management plan, 61
 - Risk Priority Number (RPN), 132, 135
 - risk ratings, 59, 61
 - robust design, 63–64
 - process map, 251–252
 - strategy flowchart, 159
 - robustness, 151, 223
 - Taguchi’s definition, 238
 - robust product, 63
 - Roman numeral notation, 177
 - root-cause analysis, 228
 - rubber gaiter example, 239–240
- S**
- scatterplots, 183–184
 - segmentation, 86–88
 - principle, 103
 - self-service principle, 108
 - sensitivity, 170
 - severity of effects ranking system, 126
 - Shewhart, Walter A., 25
 - Shiba, Shoji, 26
 - short-term data, 247
 - sigma calculations, and reliability
 - design, 241–248
 - sigma shift, 247–248
 - sigma value difference example, 247
 - signal, 169
 - signal factors, and P-Diagram, 140, 142–143
 - signal parameter, 191
 - signal-to-noise ratio, 66
 - ANOVA techniques, 67
 - and dB scale, 146
 - and ideal function, 93
 - response plot, 93
 - Taguchi on, 159
 - skipping principle, 107
 - slope calculation, 186–187
 - smaller-the-better, 2, 34, 206, 245
 - S/N. *See* signal-to-noise ratio

- SNR. *See* signal-to-noise ratio
- Society of Automotive Engineers (SAE), 116
- Sony, and quality, 223–224
- special-cause variation, 128, 236
- spheroidality, 88–90, 106
- static electricity example, 234
- static Parameter Design, 157
- static response, 2, 93
- statistical quality control, 26
- steering column example, 235
- strength degradation, 238–240
- strength distribution, 232–233, 235
- stress distribution, 232, 234
- stress–strength interference, and reliability design, 231–241
- strong oxidants principle, 110–111
- subfunctions, 56
- subjective perception, 5
- sweetness/stirring example, 39–41
- symbols in technical responses, 59, 61
- system design stage, 64
- T**
- Taguchi, Genichi, 26, 209, 217
- definition of quality, 149
 - on failures, 191
 - L_8 orthogonal array, 16
 - Loss to Society, 64
 - method, 65, 191
 - and orthogonal arrays, 15–16
 - Quality Loss Function, 149–150
 - on robustness, 238
 - System of Experimental Design*, 23, 49, 74
 - Taguchi Methods*, 161, 194
 - three phases of P-Diagram, 156–158
- taking out principle, 79, 103
- tea example, 39–41
- team selection, 166
- technical contradiction, 81
- technical responses, 59, 61
- testing
- options, 68–69
 - of prototypes, 69
 - and QFD, 68–73
- Theory of Inventive Problem Solving (TRIZ)
- contradiction, 79–84
 - control factor effects, 93–96
 - developer, 78
 - 40 inventive principles, 84–92, 103–111
 - interaction effects, 99–102
 - noise factor effects, 96–99
 - and Six Sigma design, 77–78
 - 39 engineering parameters, 83–84
- thermal expansion principle, 110
- 39 engineering parameters, 83–84
- three-period pattern, failure rates, 238
- three-phase approach, 156–158, 199–200
- tile company example, 154–155
- Tolerance Design, 64, 156–158
- compared with tolerancing, 197–201

INDEX

Tolerance Design *continued*

- concepts, 210–215
- and QLF, 204–210
- selective tolerance tightening, 203–204
- variability, 201–202
- Wheatsone Bridge, 210–213

Total Quality Management (TQM), 26

TRIZ. *See* Theory of Inventive Problem Solving

two-axis plot, 27

U

- universality principle, 104
- unreliability measures, 223
- upper specification limit (USL), 148
- U.S. Council for Automotive Research (USCAR), 116
- useful life, 219

V

- values, detection, 129
- variability reduction, and Kano Model, 40–42

variables

- design, 241
- response, 139

variation

- common-cause, 235–236
- output, 213, 245
- special-cause, 128, 236
- unit-to-unit, 142, 147

verify reliability performance, 226

VOCs (Voice-of-Customers), 4–6, 25, 168

W

- weighting factors, 59, 61
- Wheatsone Bridge, and Tolerance Design, 210–213
- white noise, 101

Z

- zero (as ideal value), 2
- zero (as target in Parameter Design), 157
- zero Loss to Society, 148